


## SoftwareUserManual

1. How to connect the Debug port of RZ/G1C Pi SBC with host PC / What are the settings to be done in host side to connect the debug port of RZ/G1C Pi SBC?

Refer the below image to connect the Debug port.



## RZ/G1C\_SBC's USB Serial Cable

